

AB w/ PASSIVE Pickups

Instructions for installing the AB on the Output of the Guitar (w/ Tone on all 3 Plups)

- 1) Mount the EMG-AB in the guitar. This may require drilling a 5/16 inch (8mm) hole.
- 2) Disconnect and remove the wire connecting between the tip terminal of the output jack and the volume control or switch.
- 3) Solder the green wire of the EMG-AB to the tip terminal of the output jack.
- 4) Solder the white wire of the EMG-AB to the volume control or switch where the old output wire was connected.
- 5) Solder one black wire of the EMG-AB to the case of a control. Solder the other black wire to the sleeve terminal of the output jack.

- 6) Solder the red wire of the EMG-AB together with the red wires from the battery clip and the EMG pickups. Cover this connection with heat shrink tubing.

This completes the installation. If you have problems, contact the factory at the number provided on the front page of these instructions. Service is readily available.

If your installation is different from the diagrams in these instructions diagrams are available on the EMG website www.emginc.com It is highly possible the website will have the diagram you require.

EMG-AB on the output with a single volume control.

