

VOCAL LINE

VOCAL FX
MIX CH1

GUITAR LINE

BUFFER
VOCAL FX (thru)
TUNER
COMP
SYNTH (dry)
OVERDRIVE
PREAMP
IR LOADER
VOLUME
PHASER (stereo)
DELAY (stereo)
REVERB (stereo)
MIX CH2/3

SYNTH LINE

SYNTH (effect)
MINI DELAY
MINI REVERB
MIX CH4

PB front



PWR A

5x120mA@9VDC

- 1) 80mA@9VDC - MINI DEL.
- 2) 79mA@9VDC - MINI REV.
- 3) 10mA@9VDC -
- 4) 79mA@9VDC - DELAY
- 5) 83mA@9VDC - REVERB

PWR B

5x120mA@9VDC

- 1) 10mA@9VDC - BUFFER
- 2) 100mA@9VDC - SYNTH
- 3) 22mA@9VDC - VOLUME
- 4) 79mA@9VDC - OD
- 5) 70mA@9VDC - PHASER

PWR C

3x300mA@9VDC

2x500mA@9/12/18VDC


- 1) 42mA@9VDC - TUNER
- 2) 76mA@9VDC - COMP
- 3) 240mA@9VDC - PREAMP
- 4) 189mA@12VDC - IR
- 5) 250mA@12VDC - VOCAL

PWR D

2x150mA@18,5VAC

- 1) MIXER

PB rear



PB front

