

PB front

GUITAR LINE

TUNER
COMPRESSOR
SYNTH (DRY)
FUZZ
VOL/WAH
PITCH
DISTORTION
PREAMP/CAB
CHORUS
DELAY
REVERB
EQ
ABY

SYNTH LINE

SYNTH (FX)
DELAY
REVERB
ABY



PWR A

5x120mA@9VDC

- 1) 20mA@9VDC - FUZZ
- 2) 20mA@9VDC - DIST
- 3) 4mA@9VDC - EQ
- 4) 4mA@9VDC - ABY
- 5) 80mA@9VDC - DELAY

PWR B

5x120mA@9VDC

- 1) 42mA@9VDC - TUNER
- 2) 76mA@9VDC - COMP
- 3) 4mA@9VDC - ABY BUFF
- 4) 22mA@9VDC - VOLUME
- 5) 70mA@9VDC - PITCH


PWR C

3x300mA@9VDC

2x500mA@9/12/18VDC

- 1) 83mA@9VDC - REVERB
- 2) 79mA@9VDC - DELAY
- 3) 70mA@9VDC - CHORUS
- 4) 240mA@9VDC - PREAMP
- 5) 100mA@9VDC - SYNTH

PB rear



PB front

